

DEBUGGING W/ FLOXGLOVE

Friday, July 05, 2024 11:37 AM

1. Prerequisites:

a. Camera Data: We can publish debug images from

"b3rb_ros_line_follower/b3rb_ros_line_follower/b3rb_ros_edge_vectors.py".

- i. Create a new publisher in the `__init__` function as shown in the attached image. We need to create a new topic and in our case we have chosen `"/debug_images/vector_image"`.

```
50 def __init__(self):
51     super().__init__('edge_vectors_publisher')
52
53     # Subscription for camera images.
54     self.subscription_camera = self.create_subscription(
55         CompressedImage,
56         '/camera/image_raw/compressed',
57         self.camera_image_callback,
58         QOS_PROFILE_DEFAULT)
59
60     # Publisher for edge vectors.
61     self.publisher_edge_vectors = self.create_publisher(
62         EdgeVectors,
63         '/edge_vectors',
64         QOS_PROFILE_DEFAULT)
65
66     # Publisher for thresh image (for debug purposes).
67     self.publisher_thresh_image = self.create_publisher(
68         CompressedImage,
69         "/debug_images/thresh_image",
70         QOS_PROFILE_DEFAULT)
71
72     # Publisher for vector image (for debug purposes).
73     self.publisher_vector_image = self.create_publisher(
74         CompressedImage,
75         "/debug_images/vector_image",
76         QOS_PROFILE_DEFAULT)
```

- ii. Now, pass this publisher (`self.publisher_vector_image`) and the image as arguments to the `"publish_debug_image"` function whenever you want to output your debug images.
- iii. `cd ~/cognipilot/cranium`
- iv. `colcon build`
- v. `source install/setup.bash`
- vi. Add the same topic name `"/debug_images/vector_image"` to the `default_value` of `topic_whitelist` in `electrode/src/electrode/launch/electrode.launch.py` as shown in the attached image.

```
53 DeclareLaunchArgument('topic_whitelist',
54     default_value=[
55         "/camera/image_raw/compressed", "/camera/camera_info", "/cerebri/out/status",
56         "/cerebri/out/nav_sat_fix", "/global_costmap/costmap", "/map", "/global_costmap/published_footprint",
57         "/plan", "/robot_description", "/tf", "/debug_images/thresh_image",
58         "/debug_images/vector_image", "/debug_images/object_recog", "/scan"]],
59     description='topic_whitelist for foxglove'
60 ),
```

- vii. `cd ~/cognipilot/electrode`
- viii. `colcon build`
- ix. `source install/setup.bash`

b. LIDAR Data:

- i. Add `"/scan"` to the `default_value` of `topic_whitelist` in `electrode/src/electrode/launch/electrode.launch.py` as shown in the attached image.

```
53 DeclareLaunchArgument('topic_whitelist',
54     default_value=[
55         "/camera/image_raw/compressed", "/camera/camera_info", "/cerebri/out/status",
56         "/cerebri/out/nav_sat_fix", "/global_costmap/costmap", "/map", "/global_costmap/published_footprint",
57         "/plan", "/robot_description", "/tf", "/b3rb_ros_line_follower/thresh_image", "/b3rb_ros_line_follower/vector_image", "/scan"]],
58     description='topic_whitelist for foxglove'
59 ),
```


- ii. `cd ~/cognipilot/electrode`
- iii. `colcon build`
- iv. `source install/setup.bash`

2. Launching Foxglove:


- a. `ros2 launch electrode electrode.launch.py sim:=True`

b. Camera Data:


- i. Create a new Image panel as shown in the attached image.




- ii. Then click on panel settings and select the topic for which you created a publisher in the "prerequisites" section.



- iii. Now this panel will display the image whenever you publish a debug image from your code to the said topic.
- c. LIDAR Data:
 - i. Create a new 3D panel by clicking on the add panel button from the top-left corner as shown in the attached image.




- ii. You may switch to 2D camera since the LIDAR is 2D.




- iii. Then click on panel settings.






iv. Toggle visibility of "/scan" under Topics.



v. Then select "lidar_link" in Display frame.



vi. You may close the panel settings after this.

vii. Please see the attached images for sample output.

